

Mug Press

How to change a Digital Controller

Replacement/Removal of Digital Controller

N.B. Before undertaking any work, switch off the power supply to the machine and unplug the machine from the electricity supply

1. Switch off machine and disconnect from power supply
2. Remove rear Cover of Press by unscrewing the seven retaining screws (pic 1)
3. Using a 7 mm spanner remove the two Dome Nuts holding the Controller in place onto L/H side Facia (pic 2)
4. Lift out Controller gently from rear of Press (pic 3) and remove all wiring, taking note of the position of all connections for future reference when reinstalling

Re-installation of replacement Digital Controller

1. Installation is a reversal of removal

