

Beta Swift Heat Press

How to change a Rocker Switch


Replacement/Removal of Rocker Switch

N.B. Before undertaking any work, switch off the power supply to the machine and unplug the machine from the electricity supply


1. Remove six screws from Base Board (pic 1)
2. Remove Base Board from Casting
3. Remove wires connected to Rocker Switch (pic 2), taking note of the connections for future reference when reinstalling new Rocker Switch
4. Remove Rocker Switch from Facia (pic 3)

Re-installation of replacement Rocker Switch

1. Installation is a reversal of removal



pic 1



pic 2



pic 3