

## **Delta Cap Press**

## How to change a Micro Switch

## Replacement/Removal of Micro Switch

- Before undertaking any work, switch off the power supply to the machine and unplug the machine from the electricity supply
- 1. Remove Rear Cover Plate and 8 screws (pic 1)
- 2. Disconnect wires connected to Micro Switch (pic 2 arrow-a), taking note of their position for future reference when reinstalling
- 3. Remove 2 screws securing Micro Switch (pic 2 arrow-b)



- 1. Installation is a reversal of removal
- N.B. When refitting Micro Switch be sure to check that it functions correctly when Heat Plate is moved into the down position and adjust if necessary



