

Omega Series 1000-1001 Heat Press

How to change a Digital Controller

Replacement/Removal of a Digital Controller

- Before undertaking any work, switch off the power supply to the machine and unplug the machine from the electricity supply
- 1. Remove the four screws securing the Instrument Box Lid and lift off from Instrument Box (pic 1)
- 2. Disconnect all wiring to Controller (pic 2), taking note of connections for future reference when reinstalling
- Remove Controller Retaining Nuts (pic 3) 3.
- 4. Lift Controller out of Instrument Box, taking note of the position of Nylon Spacers and Circuit Board connections for future reference when reinstalling

Re-installation of replacement Digital Controller

1. Installation is a reversal of removal





