

Studio Clam Press

How to change a Digital Timer

Replacement/Removal of Digital Timer

N.B. Before undertaking any work, switch off the power supply to the machine and unplug the machine from the electricity supply

1. Remove six screws from Rear Cover (pic 1)
2. Remove Rear Cover from Instrument Cover
3. Remove wires connected to Digital Timer (pic 2), taking note of the connections for future reference when reinstalling new Timer
4. Lift up tabs (on Both sides) of Retaining Bracket (pic 3) and push Digital Timer out through Instrument Cover and Facia, taking note of their position for future reference when reinstalling new Digital Timer

Re-installation of replacement Digital Timer

1. Installation is a reversal of removal

