

Technical Support

Test procedures		BETA CAP/ POCKET COMBO
Symptoms	Test procedure	Probable cause and fix
Heat press going over set temperature		 Faulty thermo couple Faulty controller
Timer does not activate (start counting down)	Pressure lever in down position	 Faulty connection/loose on controller or micro switch Faulty micro switch
Timer does not reset (buzzer does not stop)	Lever in up position	 Micro switch needs adjusting Faulty micro switch
Heat fault on digital display		 Faulty controller Open circuit on element
Probe fault on digital display		 Loose connection on controller connector block (probe) Faulty probe (thermo couple)
CAL fault on digital display		Controller needs recalibrating
Heat plate not heating	Digital display not illuminating	 Check power supply and fuse Faulty fuse holder/ switch Faulty wiring or connector Faulty controller
	Open circuit on element	 Faulty thermal cut-out Faulty wiring or connector Faulty heat element
Pressure low when Press is operated	When pressing lever is moved down	1. Handwheel needs adjusting
When pressing lever is raised to the up position it keeps falling down		1. Broken or damaged arm springs

If after following this technical support document you require any further assistance, please open a support ticket using this link: https://aadkins.com/technical-support/ and a member of our technical team will contact you