



How to change a digital controller

OMEGA SERIES 1000-1001

Replacement/ removal of a digital controller

- N.B.** Before undertaking any work, switch off the power supply to the machine and unplug the machine from the electricity supply
1. Remove the four screws securing the Instrument box lid and lift off from instrument box (pic 1)
 2. Disconnect all wiring to controller (pic 2), taking note of connections for future reference when reinstalling
 3. Remove controller retaining nuts (pic 3)
 4. Lift controller out of instrument box, taking note of the position of nylon spacers and circuit board connections for future reference when reinstalling

Re-installation of replacement digital controller

1. Installation is a reversal of removal

