

How to change a micro switch

BETA CAP/ POCKET COMBO

Replacement/ removal of micro switch

N.B. Before undertaking any work, switch off the power supply to the machine and unplug the machine from the electricity supply

1. Remove four screws from base board (pic 1)
2. Remove base board from casting
3. Remove wires from micro switch (pic 2 arrow-a)
4. Remove two screws securing micro switch bracket to casting (pic 2 arrow-b)
5. Lift bracket and micro switch out of casting
6. Remove micro switch from bracket, taking note of the position of all connections for future reference when reinstalling

Re-installation of replacement micro switch

1. Installation is a reversal of removal

