

## **Technical Support**

## How to change a micro switch

## **OMEGA SERIES 1000-1001**


## Replacement/ removal of micro switch

- **N.B.** Before undertaking any work, switch off the power supply to the machine and unplug the machine from the electricity supply
- 1. Remove the eight screws securing the rear box lid and lift off from rear box (pic 1)
- **2.** Remove screws securing micro switch to bracket (pic 2)
- 3. Remove cover and disconnect wires, taking note of the connections for future reference when reinstalling



- 1. Installation is a reversal of removal
- **N.B.** After switch is refitted, make sure it is operating in both the left and right pressing positions





If after following this technical support document you require any further assistance, please open a support ticket using this link: https://aadkins.com/technical-support/ and a member of our technical team will contact you