



How to change a plug and socket heater/ element assembly

STUDIO MUG

Replacement of a heater/ element assembly

N.B. Before undertaking any work, switch off the power supply to the machine and unplug the machine from the electricity supply

1. Remove base cover and two screws (pic 1)
2. Hold plug and socket together and turn unlock ring anticlockwise to release (pic 2)
3. Loosen two socket bracket screws (pic 2 arrow-a)
4. Remove six element retaining screws and retaining plates (pic 3)
5. Slide element assembly out of movable jaw (pic 4) guiding element wire and plug out from hole in cast body (pic 5)



Re-installation of a heater/ element assembly

1. Installation is a reversal of removal
2. Check plug locating groove is aligned with raised key in socket when pushing plug into socket (pic 6)

