

Technical Support

How to change a rocker switch


BETA SWIFT


Replacement/ removal of rocker switch

- **N.B.** Before undertaking any work, switch off the power supply to the machine and unplug the machine from the electricity supply
- 1. Remove six screws from base board (pic 1)
- 2. Remove base board from casting
- 3. Remove wires connected to rocker switch (pic 2), taking note of the connections for future reference when re-installing new rocker switch
- **4.** Remove rocker switch from fascia (pic 3)

Re-installation of replacement rocker switch

1. Installation is a reversal of removal







If after following this technical support document you require any further assistance, please open a support ticket using this link: https://aadkins.com/technical-support/ and a member of our technical team will contact you