





How to change a main control unit

STUDIO CLAM 38

Replacement/ removal of a main control unit

- N.B.** Before undertaking any work, switch off the power supply to the machine and unplug the machine from the electricity supply
1. Remove rear cover by unscrewing 8 retaining screws (pic 1)
 2. Remove main control unit cover by unscrewing retaining screw (pic 2)
 3. Remove ribbon cable connectors (pic 3)
 4. Disconnect all wires attached to main control unit (pic 4 arrow-a), taking note of their position for future reference when reinstalling
 5. Remove main control unit from machine by unscrewing retaining screws (pic 4 arrow-b)



Re-installation of replacement main control unit

1. Installation is a reversal of removal