

Beta 'Swift' Heat Press

Settings Guide

Application procedure:

- Place the garment on the pressure pad, removing all wrinkles.
- Place the label in the desired position.
- Using both hands gently pull the handle forward into the locked position, ensuring the work piece is firmly clamped between the heat plate and pressure pad.
- When the pre-set dwell time has been reached, a buzzer will sound. The heat plate should then be lifted by pushing the handle back to its full extent, again using both hands.
- For safety reasons, it is necessary to push the handle into the locked position after it is lifted. This will ensure the accidental lowering of the heat platen handle.

Care Guide:



Temperature/ Time:

200°C (392°F) with a time of 12 Seconds.

N.B. For a more comprehensive guide to these settings please refer to User Guide.

Adkins Labelling Solutions
for Nursing and Residential Care Homes

