

Omega Series 1000-1001 Heat Press

How to change a Rocker Switch

Replacement/Removal of Rocker Switch

N.B. Before undertaking any work, switch off the power supply to the machine and unplug the machine from the electricity supply

1. Remove the four screws securing the Instrument Box Lid and lift off from Instrument Box (pic 1)
2. Disconnect wires connected to Rocker Switch (pic 2), taking note of the connections for future reference when reinstalling
3. Push Rocker Switch out from Instrument Box

Re-installation of replacement Rocker Switch

1. Installation is a reversal of removal

