

Studio Auto Clam Senior/Junior Press

Symptoms	Test Procedure	Probable Cause and Fix
Heat Press going over set temperature		1. Faulty Control Panel
Timer does not activate (start counting down)	Pressure Lever in down position	1. Faulty connection/loose on Control Panel 2. Faulty Magnetic Switch
Timer does not reset	Pressure Lever in up position	1. Faulty Magnetic Switch
Pressure Lever does not stay down during set pressing time	Magnet not being energised	1. Faulty Magnetic Switch 2. Faulty Connection on Control Panel 3. Faulty Electrical Magnet
	Magnet Energised	1. Excessive printing pressure 2. Reduce pressure with Hand Wheel
Pressure Lever does not return to up position	Pre set time as counted down	1. Low printing pressure 2. Adjust pressure with Hand Wheel 3. Faulty Air Springs
Heat Plate not heating	On/Off Switch not illuminating	1. Check power supply 2. Faulty Fuse in Plug
	Control Panel not illuminating	1. Faulty Fuse in Plug 2. Circuit Breaker needs resetting 3. Faulty Control Panel
	No power to Heat Plate	1. Faulty Control Panel 2. Faulty Probe
	Open Circuit on Heat Plate	1. Faulty wiring or Connector 2. Faulty Heat Plate