

## Studio Cap Press

### Symptoms

### Test Procedure

### Probable Cause and Fix

Heat Press going over set temperature

1. Faulty Controller
2. Faulty Probe

Timer does not activate (Start counting down)

Operating Arm in down position

1. Faulty connection on Controller
2. Micro Switch needs adjusting
3. Faulty Micro Switch

Timer does not reset (Buzzer does not stop)

Operating Arm in up position

1. Micro Switch needs adjusting
2. Faulty Micro Switch

Element not heating

Controller not illuminating

1. Check power supply
2. Faulty Fuse in Plug or Fuse Holder
3. Faulty Controller

No power to Element

1. Faulty Controller

Open Circuit on Element

1. Faulty wiring or Connector
2. Faulty Heater Element

Error on Display and Buzzer sounds

1. Faulty Probe or Connector

Temp. rising LED (solid)

1. Faulty Controller

Temp. hold LED (solid)