

Studio Clam Press

Symptoms

Test Procedure

Probable Cause and Fix

Heat Press going over set temperature

1. Faulty Thermo Couple
2. Faulty Digital Heat Controller

Timer does not activate (start counting down)

Pressure Lever in down position

1. Faulty connection/loose on Digital Timer or Micro Switch

Timer does not reset (Buzzer does not stop)

Pressure Lever in up position

1. Micro Switch needs adjusting
2. Faulty Micro Switch

Heat Plate not heating

Digital Heat Controller not illuminating

1. Check power supply and Fuse
2. Faulty Fuse Holder/Switch
3. Faulty wiring or Connector
4. Faulty Solid State Relay
5. Faulty Digital Heat Controller

Open circuit on Element

1. Faulty Thermal Cut-Out
2. Faulty wiring or Connector
3. Faulty Heat Element

When Pressing Lever is raised to the up position it keeps falling down

1. Broken or damaged Return Spring(s)