

Studio Plate Press

Symptoms

Test Procedure

Probable Cause and Fix

Heat Press going over set temperature

1. Faulty Controller unit
2. Faulty Heater/Element assembly

Timer does not activate (start counting down)

Pressure Lever in forward position

1. Faulty connection on Controller unit
2. Micro Switch needs adjusting
3. Faulty Micro Switch

Timer does not reset (Buzzer does not stop)

Pressure Lever in back position

1. Micro Switch needs adjusting
2. Faulty Micro Switch

Element not heating

On/Off Switch not illuminating

1. Check power supply
2. Faulty Fuse in Plug or Socket

Controller unit not illuminating

1. Faulty Fuse in Plug or Socket
2. Faulty Controller unit

No power to Element

1. Faulty Controller unit

Open Circuit on Element

1. Faulty wiring or Connector
2. Faulty Element assembly

ERR on Display and Buzzer sounds

1. Faulty wiring or Connector between Controller unit and Element assembly
2. Faulty Element assembly

Temp. Rising LED (solid)
Temp. Hold LED (solid)

1. Faulty Controller unit