



## Test procedures

## STUDIO CAP

Symptoms	Test procedure	Probable cause and fix
Heat press going over set temperature		<ol style="list-style-type: none"><li>1. Faulty controller</li><li>2. Faulty probe</li></ol>
Timer does not activate (start counting down)	Operating arm in down position	<ol style="list-style-type: none"><li>1. Faulty connection on controller</li><li>2. Micro switch needs adjusting</li><li>3. Faulty micro switch</li></ol>
Timer does not reset (buzzer does not stop)	Operating arm in up position	<ol style="list-style-type: none"><li>1. Micro switch needs adjusting</li><li>2. Faulty micro switch</li></ol>
Element not heating	Controller not illuminating	<ol style="list-style-type: none"><li>1. Check power supply</li><li>2. Faulty fuse in plug or fuse holder</li><li>3. Faulty Controller</li></ol>
	No power to element	<ol style="list-style-type: none"><li>1. Faulty controller</li></ol>
	Open circuit on element	<ol style="list-style-type: none"><li>1. Faulty wiring or connector</li><li>2. Faulty heater element</li></ol>
	Error on display and buzzer sounds	<ol style="list-style-type: none"><li>1. Faulty probe or connector</li></ol>
	Temp. rising LED (solid) Temp. hold LED (solid)	<ol style="list-style-type: none"><li>1. Faulty controller</li></ol>