

## Delta Junior Heat Press

### How to change an On/Off Switch

#### Replacement/Removal of On/Off Switch

**N.B.** Before undertaking any work, switch off the power supply to the machine and unplug the machine from the electricity supply

1. Remove Instrument cover by bunscrewing two securing screws (pics 1 & inset reverse view)
2. Remove nut securing Switch to Instrument Cover (pic 1 arrow-a)
3. Pull Switch out from Instrument Cover
4. Disconnect wires from Switch (pic 2), taking note of the position of all connections for future reference when reinstalling

#### Re-installation of replacement On/Off Switch

1. Installation is a reversal of removal

