



ADKINS
HEAT PRESS TECHNOLOGY

Technical Support

How to change a rocker switch

OMEGA SERIES 1000-1001

Replacement/ removal of rocker switch

- N.B.** Before undertaking any work, switch off the power supply to the machine and unplug the machine from the electricity supply
1. Remove the four screws securing the Instrument box lid and lift off from instrument box (pic 1)
 2. Disconnect wires connected to rocker switch (pic 2), taking note of the connections for future reference when reinstalling
 3. Push rocker switch out from instrument box

Re-installation of replacement rocker switch

1. Installation is a reversal of removal

